



-
- ① SP-288 Centre Bolt & Nut for LP-22/33
 - ② SP-242 Pipe for LP-22S/33S with Grip
 SP-243 Pipe for LP-22M/33M with Grip
 SP-244 Pipe for LP-22L/33L with Grip
 - ③ SP-245 Screw Retainer Set
 - ④ SP-246 Bumper Socket for LP-22/33 (1pc)
 - ⑤ SP-248 Shock Absorber for LP-22S/33S (1pc)
 SP-249 Shock Absorber for LP-22M/33M (1pc)
 SP-250 Shock Absorber for LP-22L/33L/40 (1pc)
 - ⑥ SP-251 Blade Holding Bolt, Washer & Nut (1set)